

Setting Up Your New Phone Service



Step 1



Connect the RJ-11 phone cable from your phone to the Phone Adapter's PHONE 1 port. If you have a second phone line, complete this step one more time for the PHONE 2 port.

NOTE: If you have wall jacks you would like to connect the Phone Adapter to, please contact our support team.




Step 2

Disconnect the Ethernet cable from the WAN / INTERNET port on your wireless router. Plug this end into the blue INTERNET port of the Phone Adapter.




Step 3

Connect one end of the Ethernet cable included in your phone adaptor box to the yellow ETHERNET port of the Phone Adapter. Connect the other end to the WAN / INTERNET port on your wireless router.



Step 4

Connect the power adapter (included) to the Phone Adapters POWER port, and then plug the power adapter into a surge protector. The power LED on the front panel will light up as soon as the phone adapter powers on.



Step 5

Pick up the handset on your phone and verify that you hear a dial tone. Call NCI Datacom at 509-826-0300 to complete your setup.



If you have questions, or are unable to get your new phone working, please call us at 509-826-0300 or call toll free at 888-317-7624.

You may also submit a trouble ticket online at www.ncidata.com.